10-681640-00P (PIN) 10-681640-00S (SOCKET)

Contact, Pin and Socket, Differential Twinax, Installation Instructions

See table on reverse side for twinax cable recommended, tool selector settings, crimping tool, positioner and insertion/removal tool information.

- A 1. Cut cable for assembly of differential twinax contacts.
- B 1. Rubber end first, slide piggyback grommet seal back over cable jacket (not illustrated).
- Strip cable jacket to expose cable outer braid as illustrated. Ends must be cut cleanly and at right angles to the axial plane of the cable. Cable must not be deformed while making cuts.
- C 1. Slide crimp bushing, large diameter end first, over cable braid until cable jacket butts inside shoulder of crimp bushing.
- D 1. Flair cable braid back over crimp bushing as illustrated to expose inner wires. Trim excess cable braid.
 - Cut off any inner braids, wraps or cable fillers as close to outer cable braid as possible.
 - Cut inner wires to dimension shown. All wires must be cut to equal length. It
 may be helpful to cut one wire to length. Then cut remaining wire to equal
 length as the first wire.
- E 1. Strip inner wires to expose center conductors as illustrated. All wires must be stripped to equal length.
- F 1. Carefully splay inner wires perpendicular to the axis of the cable as illustrated.
 - Assemble inner contact over cable center conductor until fully seated against inner wire insulation. Observe center conductor through the contact's wire inspection hole, to make certain conductor is properly positioned.
- Crimp inner contact to center conductor using crimp tools listed in table on back. Repeat steps F2 and F3 until all inner contacts are crimped.
- G 1. Position rear insulator against cable braid as illustrated. Make certain insulator slots are aligned with splayed inner contact wires. One-by-one, position wired inner contacts inside the insulator slots as shown. The inner contact's retention shoulder must be positioned in front of the insulator's front surface as illustrated (two of the rear insulator slots will not be used).

Continued on back

L-2119-HE July2019 FSCM77820



REAR INSULATOR

REAR INSULATOR

.200 _ CRIMP AREA

SLOTS

CRIMP

BUSHING

T

OUTER CONTACT J BODY (PIN SHOWN FOR REFERENCE)

FRONT _____

Q

FRONT INSULATOR KEYWAY

> INNER CONTACTS

OUTER CONTACT ORIENTATION KEY

OUTER CONTACT

BIVET KEY

150

н

I

10-681640-00P (PIN) 10-681640-00S (SOCKET)

- H 1. With inner contacts positioned inside rear insulator slots, assemble front insulator over the inner contacts as shown. The front insulator must butt the rear insulator, and inner contact retention shoulders must enter front insulator bores.
 - 2. Observe the front insulator's keyway. When the inner pin assembly is held in the vertical position (with inner pin contacts on top), the inner pin contact with the insulator keyway to its left will be positioned at the "9 o-clock" orientation position, when viewing the pin assembly from the mating end (for inner socket contacts, the insulator keyway should be positioned to the right of the inner socket desired at the mating "3 o-clock" orientation position, when viewing the socket assembly from the mating end).
- I 1. Align front insulator keyway with the outer contact's rivet key. Slide the inner contact assembly inside the outer contact body until fully seated. Observe the mating end of the assembly to make certain the inner contacts are at the "3 o-clock" and "9 o-clock" orientation positions when the outer contact's orientation key is held at the "12 o-clock" position.
 - 2. Crimp outer contact body in the area indicated using crimp tools listed in table below.

Amphenol Part Number	Description	Twinax Cable Recommended	Inner Crimp Tools		Outer Crimp Tools	
			Tool (Setting)	Positioner	Tool	Die Set (Location)
10-681640-00P	Differential Twinax Pin (120 Ohm)	Radox Databus	M22520/2-01 (5)	Daniels K1625	M22520/5-01	Daniels Y144
10-681640-00S	Differential Twinax Socket (120 Ohm)	(.75mm ²)				

Contact Insertion into Connector

Contacts are inserted by hand. Insert the contact assembly into the proper rear grommet hole. Contact must be aligned with hole and not inserted at an angle. The contact's orientation key must be in vertical alignment with the connector's main key or keyway (holding contact key and connector key/keyway at "12 o'clock" orientation position is recommended). Push forward until contact is felt to snap into position within the insert. Contact may need to be slightly rotated to properly align contact orientation key with connector insert keyway. Gently tug on cable to assure retention. Slide piggyback grommet seal into position inside the connector grommet and over the crimped end of the contact.

Contact Removal from Connector

Remove piggyback grommet seal from the connector grommet. Position removal tool part number MIL-I-81969/14-12, Daniels DRK-264-8, around cable and slide tool toward connector until tool tips enter rear grommet and comes to a positive stop on the contact. Grip cable and simultaneously remove tool, contact and cable.

Amphenol

Amphenol Aerospace 40-60 Delaware Avenue Sidney, New York 13838-1395 Website: www.amphenol-aerospace.com

10-681640-00P (PIN)

10-681640-00S (SOCKET)

- inner contacts as shown. The front insulator must butt the rear insulator, and inner contact With inner contacts positioned inside rear insulator slots, assemble front insulator over the Ч. Η
- positioned to the right of the inner socket desired at the mating "3 o-clock" orientation po-sition, when viewing the socket assembly from the mating end). sembly from the mating end (for inner socket contacts, the insulator keyway should be its left will be positioned at the "9 o-clock" orientation position, when viewing the pin asposition (with inner pin contacts on top), the inner pin contact with the insulator keyway to Observe the front insulator's keyway. When the inner pin assembly is held in the vertical .2 retention shoulders must enter front insulator bores.
- positions when the outer contact's orientation key is held at the "12 o-clock" position. sembly to make certain the inner contacts are at the "3 o-clock" and "9 o-clock" orientation Align front insulator keyway with the outer contact's rivet key. Slide the inner contact as-sembly inside the outer contact body until fully seated. Observe the mating and of the as-'L I

Outer Crimp Tools		Inner Crimp Tools		oldo O youiwT		trea lonodara
Die Set (Location)	ΙοοΤ	Positioner	looT (gnittə2)	Bebrammoose R	Description	Mumber Number
44 LY sleinsD	M225220/5-01	Daniels K1625	(2) W552520/2-01	Radox Databus 12 552 469 (.75mm²)	Differential Twinax Pin (m10 02 r)	900-040188-01
					Differential Twinax Socket (1 20 Ohm)	S00-079189-01

Contact Insertion into Connector

end of the contact. Gently tug on cable to assure retention. Slide piggyback grommet seal into position inside the connector grommet and over the crimped tion within the insert. Contact may need to be slightly rotated to properly align contact orientation key with connector insert keyway, key and connector key/keyway at "12 o'clock" orientation position is recommended). Push forward until contact is felt to snap into posiinserted at an angle. The contact's orientation key must be in vertical alignment with the connector's main key or keyway (holding contact Contacts are inserted by hand. Insert the contact assembly into the proper rear grommet hole. Contact must be aligned with hole and not

and simultaneously remove tool, contact and cable. 8, around cable and slide tool toward connector until tool tips enter rear grommet and comes to a positive stop on the contact. Grip cable Remove piggyback grommet seal from the connector grommet. Position removal tool part number MIL-I-81969/14-12, Daniels DRK-264-

150

IonendmA

Sidney, New York 13838-1395 90060 Delaware Avenue Amphenol Aerospace



CRIMF

BUSHING

INNER CONTACTS

I Ć ABRA CRIMP OUTER CONTACT ORIENTATION KEY 500 ROTAJUZNI SLOIS TNORT ROTAJUZNI RAJR CONTACTS INNER н **YAWY3X ROTAJU2NI**

ROTAJUŻNI RAJR

FOR REFERENCE) 2. Crimp outer contact body in the area indicated using crimp tools listed in table below. NWOHS NIG) YOOR В∩ЗНІИС СВІМЬ — DUTER CONTACT-

Contact Removal from Connector

TWINAX

Website: www.amphenol-aerospace.com

- Position rear insulator against cable braid as illustrated. Make certain insula-G 1. tor slots are aligned with splayed inner contact wires. One-by-one, position wired inner contacts inside the insulator slots as shown. The inner contact's retention shoulder must be positioned in front of the insulator's front surface
- as illustrated (two of the rear insulator slots will not be used).

- back. Repeat steps F2 and F3 until all inner contacts are crimped.

- Crimp inner contact to center conductor using crimp tools listed in table on

- length as the first wire. E 1. be stripped to equal length. F
- may be helpful to cut one wire to length. Then cut remaining wire to equal
- Cut inner wires to dimension shown. All wires must be cut to equal length. It 3.
- - Strip inner wires to expose center conductors as illustrated. All wires must

possible.

Cut off any inner braids, wraps or cable fillers as close to outer cable braid as 2.

1. ed.

2.

Carefully splay inner wires perpendicular to the axis of the cable as illustrat-Assemble inner contact over cable center conductor until fully seated against inner wire insulation. Observe center conductor through the con-

tact's wire inspection hole, to make certain conductor is properly positioned.



FSCM77820



illustrated).

Continued on back

OUTER CONTACT RIVET KEY

INOH

L-2119-HE

July2019

Β1.

C 1.

D 1.

2.

Contact, Pin and Socket, Differential Twinax, Installation Instructions

See table on reverse side for twinax cable recommended, tool selector settings

jacket butts inside shoulder of crimp bushing.

be deformed while making cuts.

wires. Trim excess cable braid.

crimping tool, positioner and insertion/removal tool information.

A 1. Cut cable for assembly of differential twinax contacts.